




REFUEL






Please refuel through this pipe.



Connect the pipe which is at the end of the main tank to a syringe. When the main tank is full please make that the pipe is well connected to the syringe to avoid leakage of oil, then proceed to fill up the external tanks.



When all fuel tanks are filled with fuel you will need to inject some air back to the fuel pipe to avoid siphon phenomenon.



THE ART OF PERFORMANCE